

HUBBARD COMMUNICATIONS OFFICE
Saint Hill Manor, East Grinstead, Sussex

HCO BULLETIN OF 10 DECEMBER 1976

Remimeo
ALL AUDITORS
ALL INTERNE
SUPERVISORS
ALL C/Ses

URGENT - IMPORTANT

C/S Series 99

F/N AND TA POSITION

Through verbal tech just located, it has been found that some Auditors have been ordered to disregard all F/N's that were above 3.0 or below 2.0 on the meter.

Auditors have also called F/Ns which were ARC Break needles, thus falsely indicating to the pc.

These two actions -- disregarding actual F/Ns because the TA was not between 2.0 and 3.0 and calling "F/Ns" that were actually ARC Break needles -- have upset many preclears.

The outnesses here are: A. not considering pc indicators as senior and B. not noting pc indicators when calling an F/N and C. ignoring and giving junior importance to the technology covered in False TAs. (See list of references at end of this HCOB or the Subject Index of the HCOB Volumes.)

Auditors have even been led to falsify worksheets (giving TA as in range when it actually was not when calling an F/N) because they might "get in trouble" for calling an F/N in the wrong range, such as 1.8 or 3.2.

The CORRECT procedure for out of range F/Ns is:

1. Look at the pc's indicators.
2. Call the F/N regardless of its range.
3. Mark down the ACTUAL TA position.
4. Handle the False TA at the earliest opportunity when it will not intrude into the current cycle on which the pc is being audited. (You don't interrupt a Quad R3R, for instance, to handle False TA; you complete it and then, when directed by the C/S, you handle the False TA.)
5. On any pc you suspect has had his F/Ns disregarded because of False TA, you C/S for and get run a repair and rehab of this error.

E-Meter cans can monitor or change TA position when the palms are too dry or too wet or when the cans are too big or too small or when the wrong hand cream is used. The E-Meter does not read on hand moisture alone as was long believed by people in electronics. But TA depends upon resistance to electrical current in the palms, leads, and meter as well as its main resistance which happens to be mental masses or lack of them.

To simply tell some Interne "Always disregard an F/N not in correct range" is to set him up for loses and set the pc up for crashes. The correct information is that an F/N which isn't in range is accompanied by pc indicators that indicate whether it is an F/N or not. AND indicates you better get the False TA handled as fast as soon as it won't interrupt the current cycle. AND you always note where it F/Ned so the C/S can C/S for False TA handling.

Where an ARC Break needle (which looks like an F/N) is observed, whether it is in range or out of range (2.0 to 3.0 or below 2.0 or above 3.0) you LOOK at the pc and establish the pc's indicators before falsely calling an F/N. A pc who is about to cry is NOT an F/Ning pc and if you indicate an F/N to that pc you will further the ARC Break and suppress the emotional charge that is about to come off.

REPAIR

Where the above matters have not been fully understood and errors have occurred on pcs, it must be assumed that:

1. Auditors have falsified their worksheets as to TA positions and thus built up withholds and made themselves blowey.
2. That every pc who has ever had high or low TA trouble has had F/Ns disregarded and ARC Break F/Ns falsely indicated.

3. That a briefing and drilling of all Internes and Auditors must occur on this HCOB.
4. That a brief program of clean up of disregarded F/Ns and falsely called ARC Break F/Ns be done on every pc.
5. That every such pc be considered as having False TA troubles and these must be C/sed for and corrected.
6. That all Auditors and Internes be drilled on all HCOBs relating to pc indicators.

SAMPLE CLEAN UP C/S

Disregard TA position, use only F/Ns and pc indicators in doing this C/S.

1. It has been found that some of your F/Ns (release points) may have been disregarded by past or present Auditors.
2. Have you ever felt an F/N (release point or end of an action) had been by-passed on your case? E/S to F/N.
3. Find and rehab the principal overrun of a release point.
4. Have you ever felt an F/N should not have been indicated by the Auditor when it was? E/S to F/N.
5. Find the principal point and get in suppress on it and complete the action. Do this E/S to F/N.
6. Find and run the ARC Breaks by-passed with ARC Break handling.
7. Find and handle the False TA in totality.

REFERENCE HCOBs FOR FALSE TA

1. HCOB 24 Oct 71 FALSE TA
2. HCOB 15 Feb 72 FALSE TA ADDITION 2
3. HCOB 12 Nov 71R FALSE TA ADDITION
4. HCOB 18 Feb 72 FALSE TA ADDITION 3
Issue I
5. HCOB 29 Feb 72R FALSE TA CHECKLIST
6. HCOB 23 Nov 73R DRY AND WET HANDS MAKE FALSE TA
7. HCOB 23 Apr 75 VANISHING CREAM AND FALSE TA

PC INDICATORS HCOBs

1. HCOB 29 Jul 64 GOOD INDICATORS AT LOWER LEVELS
2. HCOB 28 Dec 63 INDICATORS PART ONE, GOOD INDICATORS
3. HCOB 23 May 71R RECOGNITION OF RIGHTNESS OF THE BEING
Issue VIII
Rev. 4 Dec 74
4. HCOB 22 Sep 71 THE THREE GOLDEN RULES OF THE C/S HANDLING AUDITORS
5. HCOB 21 Oct 68 FLOATING NEEDLE

L. RON HUBBARD
FOUNDER