

HUBBARD COMMUNICATIONS OFFICE  
Saint Hill Manor, East Grinstead, Sussex

HCO BULLETIN OF 15 JUNE 1971

Remimeo

(Reissued 16 July 1990 to clarify who may  
deliver this rundown. Addition not in script.)

C/S Series 37R

ADDITION

HI-LO TA ASSESSMENT RULES

(The rundown described in this bulletin may only be  
delivered at the Flag Service Organization by auditors and  
C/Ses specially trained and qualified to audit and C/S it.)

In assessing and listing the Continue process it is VITAL to  
continue to assess the seven flows and list until the entire list  
widely F/Ns.

There can be more than seven lists taken from the seven flows.

One finds a rise or blow up item, does a list on it, then  
reassesses ALL seven flows, finds the next most rising item, lists  
then and assesses ALL seven flows and finds the next most stopped  
or rising item and lists that. One just keeps this up.

Eventually, on assessing the seven flows you can only get a  
stopped needle. Then a slowed or killed F/N. One uses these for  
lists. Sometimes toward the last they blow on indication and cog.

The end of it all is the auditor assessing the seven flows  
without being able to disturb a wide, wide, persistent F/N.

THAT is the EP of the 37R process. There is no other EP.  
If not done to that EP, the 37R process is incomplete.

CLEARING FLOWS

The idea of flows should be cleared with the pc before  
assessment is done.

One can do this by getting the pc to draw them.

Don't confuse the pc with this clearing and make sure he is  
not confused before assessing the seven flows.

REPEATED ASSMT

One can take a sheet of paper lengthwise and write the seven  
flows along the left edge with lines to the right. By putting in  
dividing vertical lines one then has 10 or 12 assessments laid out  
ready to do.

LOW TA

Unless one does a THOROUGH JOB to the 37R End Phenomena on a  
low TA case, the TA will continue to go low in future sessions.

A low TA takes more times through the assessments and listing  
than a high TA.

HCOB 15.6.71  
Reiss. 16.7.90

- 2 -

CRAMMING

Auditors who can't do this well must be fully crammed on reading a needle and TA on stops, rises and blow ups.

The result, if properly done, is invariably good.

L. RON HUBBARD  
Founder

LRH:nt.rd.gm.sk.sak